

**SPARE PARTS CODES ORDERED BY OBSOLETE EQUIVALENCE**

OBSOLETE	SPARE PART CODE	DESCRIPTION
95161	PVT09695	4+N Kit Amplifier (without voice synthesizer)
98002	PVT09696	4+N Bulding Amplifier (without voice synthesizer)
98007	PVT09696	4+N Bulding Amplifier (without voice synthesizer)
98027	PVT09695	4+N Kit Amplifier (without voice synthesizer)
98087	PVT09621	100C Memokey Keypad
98098	PVT09646	100C Memokey Keypad
98187	PVT09734	2W 4+N Kit AUDIO Amplifier
98208	PVT09620	MDS Digital Keypad
98227	PVT09616	MDS Digital Display
98227	PVT09669	MDS Wall Mounted Guard Unit Display
98399	PVT09697	VDS Amplifier
98471	PVT09614	VDS/BUS2 Digital Display
98472	PVT09605	VDS Digital Display
98475	PVT09618	VDS Digital Keypad
98545	PVT09617	VDS Direct Keypad
98549	PVT09697	VDS Amplifier
98578	PVT06984	2W BUS2 AUDIO Amplifier
98589	PVT09696	4+N Bulding Amplifier (without voice synthesizer)
98600	PVT09695	4+N Kit Amplifier (without voice synthesizer)
98611	PVT06987	2W BUS2 Colour VIDEO Amplifier
98617	PVT09615	MDS Direct Display
98625	PVT09619	MDS Direct Keypad
98814	PVT09606	MDS Direct Display
98866	PVT09622	4+N AUDIO Amplifier
98906	PVT09715	1+N Amplifier Module
98920	PVT09772	MDS Digital Display N-Marine
98930	PVT09604	MDS Digital Display
99032	PVT06969	2W VDS Colour VIDEO Amplifier
99033	PVT06969	2W VDS Colour VIDEO Amplifier
99034	PVT06966	2W VDS AUDIO Amplifier
99052	PVT06969	2W VDS Colour VIDEO Amplifier
99053	PVT06969	2W VDS Colour VIDEO Amplifier
99054	PVT06966	2W VDS AUDIO Amplifier
99114	PVT09629	VDS/BUS2 Digital Keypad
99128	PVT09626	MDS Digital Display
99129	PVT09627	VDS Digital Display
99131	PVT09678	4+N Amplifier
99184	PVT09771	VDS Digital Display N-Marine
99217	PVT09697	VDS Amplifier
99318	PVT09623	VDS AUDIO Amplifier
99342	PVT09716	1+N Flat Amplifier Module
99566	PVT06966	2W VDS AUDIO Amplifier
99567	PVT06969	2W VDS Colour VIDEO Amplifier
99568	PVT06969	2W VDS Colour VIDEO Amplifier
99569	PVT06984	2W BUS2 AUDIO Amplifier
99570	PVT06984	2W BUS2 AUDIO Amplifier
99571	PVT06984	2W BUS2 AUDIO Amplifier

99572	PVT06987	2W <b>BUS2</b> Colour VIDEO Amplifier
99573	PVT06987	2W <b>BUS2</b> Colour VIDEO Amplifier
99574	PVT06987	2W <b>BUS2</b> Colour VIDEO Amplifier
99575	PVT06975	2W <b>4+N</b> AUDIO Amplifier
99583	PVT06975	2W <b>4+N</b> AUDIO Amplifier
99584	PVT06975	2W <b>4+N</b> AUDIO Amplifier
99585	PVT06975	2W <b>4+N</b> AUDIO Amplifier
99586	PVT06978	2W <b>4+N</b> Colour VIDEO Amplifier
99587	PVT06978	2W <b>4+N</b> Colour VIDEO Amplifier
99588	PVT06978	2W <b>4+N</b> Colour VIDEO Amplifier
99589	PVT06978	2W <b>4+N</b> Colour VIDEO Amplifier
99594	PVT06978	2W <b>4+N</b> Colour VIDEO Amplifier
99595	PVT06978	2W <b>4+N</b> Colour VIDEO Amplifier
99610	PVT09728	<b>MDS/VDS/BUS2/DUOX</b> Direct Keypad
99612	PVT09642	<b>MDS/VDS/BUS2</b> Digital Keypad
99622	PVT09611	<b>VDS/BUS2</b> Digital Display
99626	PVT09610	<b>MDS</b> Digital Display
99632	PVT09613	100C Memokey Keypad
99881	PVT06975	2W <b>4+N</b> AUDIO Amplifier
99930	PVT06987	2W <b>BUS2</b> Colour VIDEO Amplifier
99931	PVT06984	2W <b>BUS2</b> AUDIO Amplifier
99950	PVT09625	Colour Marine Camera
99976	PVT06975	2W <b>4+N</b> AUDIO Amplifier
99976	PVT09734	2W <b>4+N</b> Kit AUDIO Amplifier
980078	PVT09734	2W <b>4+N</b> Kit AUDIO Amplifier
980259	PVT09639	<b>BUS2</b> Colour VIDEO Amplifier Set
980260	PVT09640	<b>VDS/BUS2</b> Digital Display
980261	PVT09643	ONETOONE Module
980371	PVT09734	2W <b>4+N</b> Kit AUDIO Amplifier
980373	PVT09734	2W <b>4+N</b> Kit AUDIO Amplifier
980375	PVT09734	2W <b>4+N</b> Kit AUDIO Amplifier
980377	PVT09734	2W <b>4+N</b> Kit AUDIO Amplifier
980378	PVT09636	<b>BUS2</b> AUDIO Amplifier Set
980379	PVT09713	<b>VDS</b> Audio Amplifier AUDIO N-Marine Pushbuttons
980380	PVT09634	<b>4+N</b> AUDIO Amplifier Set
980381	PVT09703	<b>VDS</b> Video Amplifier VIDEO N-Marine Pushbuttons
980382	PVT09637	<b>4+N</b> Colour VIDEO Amplifier Set
980383	PVT09641	<b>MDS</b> Digital Display
980384	PVT09635	<b>VDS</b> AUDIO Amplifier Set
980385	PVT09638	<b>VDS</b> Colour VIDEO Amplifier Set
980387	PVT09667	Proximity Reader
980414	PVT09775	2W <b>VDS</b> Kit VIDEO Amplifier V2.2
980415	PVT09775	2W <b>VDS</b> Kit VIDEO Amplifier V2.2
980419	PVT09775	2W <b>VDS</b> Kit VIDEO Amplifier V2.2
980420	PVT09775	2W <b>VDS</b> Kit VIDEO Amplifier V2.2
980428	PVT06962	<b>VDS</b> AUDIO Keypad Amplifier
980429	PVT06963	<b>VDS</b> Colour VIDEO Keypad Amplifier
980507	PVT09805	<b>MDS</b> Digitiser Module
980512	PVT09308	Digital Keypad (B)
980564	PVT09804	<b>DUOX</b> Graphic Digital Display

980565	PVT09310	DUOX Digital Display N-Marine
980916	PVT09322	DUOX AUDIO Amplifier Digital
980917	PVT09321	2W DUOX AUDIO Amplifier Pushbuttons
980931	PVT09321	2W DUOX AUDIO Amplifier Pushbuttons
980932	PVT09321	2W DUOX AUDIO Amplifier Pushbuttons
980933	PVT09321	2W DUOX AUDIO Amplifier Pushbuttons
980934	PVT09322	DUOX AUDIO Amplifier Digital
980935	PVT09322	DUOX AUDIO Amplifier Digital
980941	PVT09323	2W DUOX VIDEO Amplifier Pushbuttons
980942	PVT09323	2W DUOX VIDEO Amplifier Pushbuttons
980943	PVT09324	DUOX VIDEO Amplifier Digital
980945	PVT09325	DUOX VIDEO Amplifier Digital
980946	PVT09326	DUOX VIDEO Amplifier Pushbuttons
980965	PVT09323	2W DUOX VIDEO Amplifier Pushbuttons
980968	PVT09286	DUOX VIDEO Amplifier Digital 1W
980987	PVT09322	DUOX AUDIO Amplifier Digital
980997	PVT09322	DUOX AUDIO Amplifier Digital
987946	PVT09328	DUOX VIDEO Amplifier Digital 1W
F01138	PVT09772	MDS Digital Display N-Marine
F01146	PVT09684	VDS Amplifier
F01159	PVT9771	VDS Digital Display N-Marine
F01160	PVT09696	4+N Bulding Amplifier (without voice synthesizer)
F01360	PVT09622	4+N AUDIO Amplifier
F01361	PVT09623	VDS AUDIO Amplifier
F01363	PVT09625	Colour Marine Camera
F02260	PVT09659	MDS Proximity Module
F02263	PVT09661	Standalone Module
F02490	PVT09671	Colour Citymax Camera
F02500	PVT09678	4+N Amplifier
F02501	PVT09672	Blank Module
F02502	PVT09679	4+N 101 Pushbutton Module
F02503	PVT09680	4+N 102 Pushbutton Module
F02504	PVT09681	4+N 103 Pushbutton Module
F02505	PVT09694	4+N 201 Pushbutton Module
F02506	PVT09682	4+N 202 Pushbutton Module
F02507	PVT09683	4+N 203 Pushbutton Module
F02508	PVT09685	VDS 101 Pushbutton Module
F02509	PVT09686	VDS 102 Pushbutton Module
F02510	PVT09687	VDS 103 Pushbutton Module
F02511	PVT09688	VDS 201 Pushbutton Module
F02512	PVT09689	VDS 202 Pushbutton Module
F02513	PVT09690	VDS 203 Pushbutton Module
F02514	PVT09684	VDS Amplifier
F02530	PVT09646	100C Memokey Keypad
F02560	PVT09659	MDS Proximity Module
F06962	PVT06962	VDS AUDIO Keypad Amplifier
F06963	PVT06963	VDS Colour VIDEO Keypad Amplifier
F06964	PVT06966	2W VDS AUDIO Amplifier
F06965	PVT06966	2W VDS AUDIO Amplifier
F06966	PVT06966	2W VDS AUDIO Amplifier

F06967	PVT06969	2W VDS Colour VIDEO Amplifier
F06968	PVT06969	2W VDS Colour VIDEO Amplifier
F06969	PVT06969	2W VDS Colour VIDEO Amplifier
F06973	PVT06975	2W 4+N AUDIO Amplifier
F06974	PVT06975	2W 4+N AUDIO Amplifier
F06975	PVT06975	2W 4+N AUDIO Amplifier
F06976	PVT06978	2W 4+N Colour VIDEO Amplifier
F06977	PVT06978	2W 4+N Colour VIDEO Amplifier
F06978	PVT06978	2W 4+N Colour VIDEO Amplifier
F06982	PVT06984	2W BUS2 AUDIO Amplifier
F06983	PVT06984	2W BUS2 AUDIO Amplifier
F06984	PVT06984	2W BUS2 AUDIO Amplifier
F06985	PVT06987	2W BUS2 Colour VIDEO Amplifier
F06986	PVT06987	2W BUS2 Colour VIDEO Amplifier
F06987	PVT06987	2W BUS2 Colour VIDEO Amplifier
F06991	PVT09613	100C Memokey Keypad
F07454	PVT09613	100C Memokey Keypad
F08780	PVT09645	INTEL Colour Camera
FE01120	PVT09626	MDS Digital Display
FE01121	PVT09627	VDS Digital Display
FE01123	PVT09629	VDS/BUS2 Digital Keypad
FE01141	PVT09695	4+N Kit Amplifier (without voice synthesizer)
FE01143	PVT09622	4+N AUDIO Amplifier
FE01145	PVT09697	VDS Amplifier
FE01149	PVT09623	VDS AUDIO Amplifier
FE05004	PVT09715	1+N Amplifier Module
FFR01108	PVT09716	1+N Flat Amplifier Module